

JRC Components Cannondale Knot / Save Stem Mount Installation

Pack Contents:

- 1x JRC Components Mount for Hollowgram Stems
- 2x Longer 22mm retention bolt

1. Pre-Installation Check:

- Ensure that you have the required tools before you begin: hex keys, a certified torque wrench and **Loctite 242 (blue)** - this is recommended by Cannondale for installation of the mounting bolts into the stem threads.
- Remove the existing 18mm retention bolts & specific **Cannondale washer plate** from your Cannondale Hollowgram stem. Retain the 18mm bolts as spares, if you should wish to remove the mount in future.
- Ensure that you have placed the silver stainless steel washers provided under the head of each bolt.
- Make sure your bike is securely placed on a bike stand or other stable surface before beginning installation.

2. JRC Knot/Save Mount Installation:

- Carefully place the **Cannondale washer plate** between the mount and the underside of the stem. This washer plate is crucial for proper mounting and stability.
- Insert both of the longer 22mm bolts through the mount and plate, putting the Loctite 242 adhesive on the bolts before threading them into the designated threaded holes in your stem.

3. Bolt tightening:

- Tighten the 2 mounting bolts *evenly* to Cannondale's recommended torque. Refer to the most recent guidance for your stem.
- The *correct* use of a certified torque wrench is recommended for precise installation.

4. Pre-Ride Check:

- After torquing the bolts appropriately, apply some vertical and lateral force to the handlebars by pushing/pulling on them, sufficient to ensure they are secure and without play so that the bike is safe to ride.

Important Note:

- It is important to follow these steps *meticulously* to guarantee the proper installation and secure usage of the Cannondale Knot / Save Stem Mount.
- If you encounter any difficulties during installation, or if you're unsure about any step, it is recommended to seek assistance from a suitably certified bicycle mechanic.

