

Low Profile Handlebar Computer Mount for Garmin/Wahoo

Pack contents:

- 1x Low Profile Handlebar CNC 6061-T6 Computer Mount (for 31.8mm diameter handlebars)
- 4x Stainless Steel Bolts
- 1x Plastic insert for either Garmin or Wahoo

1. Pre-Installation Check:

- Ensure that you have the required tools before you begin: hex keys, a certified torque wrench and grease - we recommend using lithium grease to install the mounting bolts.
- Grease the threads of the clamp bolts included with your new mount.
- Make sure your bike is securely placed on a bike stand or other stable surface before beginning installation.

2. Low Profile Computer Mount Installation:

- Position the Computer Mount on the handlebar centre clamping section.
- Insert the bolts through the bolt holes of the Mount and thread them gently into the upper mount clamp section until the mount is snug against the handlebars in the desired position.

3. Bolt tightening:

- Tighten the Computer Mount handlebar clamp bolts *evenly* to prevent over-tightening and/or stripping of the clamp threads.
- After installation, check that the mount will not move or drop before riding. Do this with the GPS device installed to check that the mount is secure.

4. Pre-Ride Check:

- After tightening the bolts appropriately to 3Nm, check that the mount is secure on the handlebars and will not move when the GPS unit is fitted before test-riding.

Troubleshooting:

- If the mount is rattling during the pre-ride check, stop and recheck the installation of both mount and device to ascertain the cause.
- Do not keep tightening the bolts without checking if there is an issue with the fit of the mount to the handlebars or the third party device to the mount.
- Once satisfied that the above items are secure and correctly fitted, test ride once again.

Additional Notes:

- If you encounter any difficulties during fitting, or are unsure about any step, it is recommended that you consult a suitably certified bike mechanic for assistance.