

Aluminium Bar-End Plugs with expander for Road + MTB

Pack Contents:

- CNC - Machined 6061 25mm Aluminium Cap,
- Black steel centre bolt, rubber expanding wedge w/alloy nut.

1. Pre-installation Check:

- Ensure your bike has a handlebar (either road or MTB) with a rounded end.
- Ensure you have the required 3mm hex key tool.
- Make sure your bike is securely placed in a stand or stable surface.

2. Remove the original bar end plug by prising it from the end of the handlebar gently or loosening it with a hex key before removing it if required.

3. Install the new plug, ensuring that any bar tape end that has come undone is tucked away inside the handlebar. If using the plug on an MTB this step won't be necessary.

4. Once inserted fully into the handlebar end, hold the JRC Bar End Plug flush with the handlebar end and tighten the hex key bolt, expanding the plug sufficiently to secure it.

5. Before riding the bike outside, recheck that the plug has indeed been secured in the handlebar end and will remain there under riding conditions.

Important Note:

- If you encounter any difficulty, it is recommended that a suitably certified professional bike mechanic is consulted for assistance.